Haier SERVICE MANUAL

Wall Mounted Type

DC Inverter

Model No.1U26JACFRA 1U35JACFRA



This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or Repair the product or products dealt with in this service information by anyone else could result in serious injury or death

> (Qingdao Haier Air Conditioner General corp., Ltd) All rights reserved. Unauthorized copying and distribution is a violation of law

Haier Group

Version: V1

Date: 2018-06-29

Contents

1. Introduction	1
2. Specifications	7
3. Sensors list	8
4. Piping diagrams	.11
5. Operation range	.12
6. PCB Diagram	.13
7. Functions and Control	17
8. Dimensional drawings	- 32
9. Conter of gravity	· 32
10. Service Diagnosis	33
11. Performance and cerves diagrams	47
12. Circuit diagrams	· 56

1 Introduction

1.1 Model name explanation



1.2 Safety Cautions

Be sure to read the following safety cautions before conducting repair work.

The caution items are classified into "Warning" and "Caution". The "Warning" items are especially important since they can lead to death or serious injury if they are not followed closely. The "Caution" items can also lead

to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety

caution items described below.

About the pictograms

- \bigtriangleup This symbol indicates an item for which caution must be exercised.
 - The pictogram shows the item to which attention must be paid.
- \circ This symbol indicates a prohibited action.
 - The prohibited item or action is shown inside or near the symbol.
- This symbol indicates an action that must be taken, or an instruction.

The instruction is shown inside or near the symbol.

After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates Normally, and explain the cautions for operating the product to the customer.

1.2.1 Caution in Repair

Warning	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for	
a repair.	
Working on the equipment that is connected to a power supply can cause an electrical shook.	9-6-
If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not	
touch any electrically charged sections of the equipment.	
If the refrigerant gas discharges during the repair work, do not touch the discharging refrigerant gas .The refrigerant gas can cause frostbite.	\bigcirc
When disconnecting the suction or discharge pipe of the compressor at the welded section, release the	
refrigerant gas completely at a well-ventilated place first.	
If there is a gas remaining inside the compressor , the refrigerant gas or cooling machine oil discharges	
when the pipe is disconnected, and it can cause injury.	
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas can generate toxic gases when it contacts flames.	0
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit.	
Be sure to discharge the capacitor completely before conducting repair work . A charged capacitor can	
cause an electrical shock.	
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug.	\sim
Plugging or unplugging the power cable plug to operate the equipment can cause an electrical shock or	(\mathbf{N})
fire.	y

Warning Do not repair the electrical components with wet hands . Working on the equipment with wet hands can cause an electrical shock Do not clean the air conditioner by splashing water. Washing the unit with water can cause an electrical shock. Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shock. Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury. Do not tilt the unit when removing it. The water inside the unit can spill and wet the furniture and floor. Be sure to check that the cooling cycle section has cooled down sufficiently before conducting repair work. Working on the unit when the cooling cycle section is hot can cause burns. Use the welder in a well-ventilated place. Using the welder in an enclosed room can cause oxygen deficiency.

1.2.2 Cautions Regarding Products after Repair

Warning		
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to		
conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools can		
cause an electrical shock, excessive heat generation or fire.		
When relocating the equipment, make sure that the new installation site has sufficient strength to		
withstand the weight of the equipment.		
If the installation site does not have sufficient strength and if the installation work is not conducted		
securely, the equipment can fall and cause injury.		
Be sure to install the product correctly by using the provided standard installation frame.	For	
Incorrect use of the installation frame and improper installation can cause the equipment to fall, resulting	integral	
in injury.	units only	
De sure to install the product occursiv in the installation frame mounted on a window frame	For	
Be sure to install the product securely in the installation frame mounted on a window frame.		
	units only	

Warning	
Be sure to use an exclusive power circuit for the equipment, and follow the technical standards related to the electrical equipment, the internal wiring regulations and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work can cause an electrical shock or fire.	
Be sure to use the specified cable to connect between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections can cause excessive heat generation or fire.	
When connecting the cable between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section can cause an electrical shock, excessive heat generation or fire.	
Do not damage or modify the power cable. Damaged or modified power cable can cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable can damage the cable.	\bigcirc
Do not mix air or gas other than the specified refrigerant (R-410A / R22) in the refrigerant system. If air enters the cooling system, an excessively high pressure results, causing equipment damage and injury.	
If the refrigerant gas leaks, be sure to locate the leak and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leak cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it can generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.	0
When replacing the coin battery in the remote controller, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

Caution

Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.

Do not install the equipment in a place where there is a possibility of combustible gas leaks
If a combustible gas leaks and remains around the unit, it can cause a fire.

Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water can enter the room and wet the furniture and floor.

1.2.3 Inspection after Repair

Warning

Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet all the way.

If the plug has dust or loose connection, it can cause an electrical shock or fire.

If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires can cause an electrical shock, excessive heat generation or fire.

Warning

Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances since it can cause an electrical shock, excessive heat generation or fire.

Caution	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the	
soldered or crimped terminals are secure. Improper installation and connections can cause excessive	
heat generation, fire or an electrical shock.	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame can	
cause the unit to fall, resulting in injury.	

Introduction

Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding can cause an electrical shock.	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 \ensuremath{M}	
ohm or higher.	
Faulty insulation can cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair.	
Faulty drainage can cause the water to enter the room and wet the furniture and floor.	

1.2.4 Using Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

1.2.5 Using Icons List

Icon	Type of Information	Description		
i _{Note}	Note	A "note" provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.		
Caution	Caution	A "caution" is used when there is danger that the reader, through incorrect manipulation, may damage equipment, loose data, ge an unexpected result or has to restart (part of) a procedure.		
	Warning	A "warning" is used when there is danger of personal injury.		
5	Reference	A "reference" guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.		

2. Specifications - 1U26JACFRA

NOMINAL DISTRIBUTION SYSTEM VOLTAGE				
Phase	/ 1			
Frequency	Hz	50		
Voltage	V	220~240		

NOMINAL CAPACITY and NOMINAL INPUT				
		cooling	heating	
Capacity rated	W	2650(1500-3200)	3300(1600-3800)	
	Btu/h	9000(5100-10900)	11200(5460-12950)	
Power Consumption(Rated)	W	500	650	
EER/COP	W/W	5.30	5.08	
Moisture Removal	m³/h	1.2*10 - ³		

TECHNICAL SPECIFICATIONS-UNIT				
Dimensions	H*W*D	mm	820×338×614	
Packaged	LI*///*D	3	003×413×685	
Dimensions		111	99344134065	
Weight	1	KG	40.6	
Gross weight	1	KG	45.0	
Sound level	Sound pressure	dB	53	
	Sound power	dB(A)	66	

ELECTRICAL SPECIFICATIONS				
	cooling	heating		
Nominal running current	А	2.35	3.0	
Maximum running current	А	4.9	6.1	

TECHNICAL SPECIFICATIONS-PARTS					
cooling heating				heating	
	Туре		Rotary Co	Rotary Compressor	
	Model		GSD088RKQA6JT6		
Compressor	Motor output	W	W 599		
	Oil type		ACS-	ACS-68R	
	Oil charge volume	L	L 0.32		
	Туре		Axial fan		
Ean	Motor output	GSD088RKQA6JT6 W 599 ACS-68R L 0.32 Axial fan W 38/49 m³/h 2100			
Fall	Air flow rate(high)	m³/h	21	00	
	Speed(high/low) rpm 800/300		/300		
Heat	Туре		ML fin- φ 7	HI-HX tube	
exchanger	Row*stage*fitch		2.5*24	*1.4	

TECHNICAL SPECIFICATIONS-OTHERS					
Refrigerant	Refrigerant type		R	R32	
circuit	Refrigerant charge		KG	1.1	
Chount	Refrigerant control		EX	V	
Dining connecti	000	liquid	mm mm	Ф6.35	
(oxtornal diama	Piping connections	gas	mm	Ф9.52	
		drain	mm	Φ17	
Heat insulation ty	Sulation type Both liquid and Gas pipes			nd Gas pipes	
Max. piping Length		m	15		
Max. Level Differ	rence		m	10	
Chargeless		m	10		
Amount of Additional Charge of Refrigerant		g/m	20		
International Pro	tection degree		IP	24	

Note: the data are based on the conditions shown in the table below

cooling	heating	Piping length
Indoor: 27°CDB/19°CWB	Indoor:20°CDB	5~
Outdoor: 35℃DB/24℃WB	Outdoor: 7℃DB/6℃WB	511

Conversation formulae	
Kcal/h= KW×860	
Btu/h= KW×3414	
cfm=m³/min×35.3	

3. Sensors list

type	Description	Qty
Ambient sensor Defrosting sensor Discharging sensor	Its used for detecting temperature of outdoor side Its used for controlling outdoor defrosting at heating mode Its used for compressor in case of over-heat	3 in 1
Suction sensor	Its used for detecting suction pipe temperature of compressor to adjust gas flowing	1

2. Specifications - 1U35JACFRA

NOMINAL DISTRIBUTION SYSTEM VOLTAGE				
Phase	/	1		
Frequency	Hz	50		
Voltage	V	220~240		

NOMINAL CAPACITY and NOMINAL INPUT				
		cooling	heating	
Capacity rated	W	3400(1300-4000)	3800(1600-4300)	
Capacity faleu	Btu/h 11600(4400-13650) 12900(5450-14)	12900(5450-14650)		
Power Consumption(Rated)	W	780	790	
EER/COP	W/W	4.36	4.81	
Moisture Removal	m³/h	1.6*	*10 - ³	

TECHNICAL SPECIFICATIONS-UNIT				
Dimensions	H*W*D	mm	820×338×614	
Packaged	LI*///*D	3	003×413×685	
Dimensions		111	993^413^003	
Weight	1	KG	40.6	
Gross weight	1	KG	45.0	
Sound loval	Sound pressure	dB	55	
Sound level	Sound power	dB(A)	65	

ELECTRICAL SPECIFICATIONS				
		cooling	heating	
Nominal running current	А	3.57	3.58	
Maximum running current	А	5.7	6.1	

TECHNICAL SPECIFICATIONS-PARTS				
		cooling	heating	
	Туре		Rotary Compressor	
	Model		GSD102UKQA6JT6	
Compressor	Motor output	W 695		
	Oil type		R M - L P 5 6 E G	
	Oil charge volume	ge volume L 0.32	32	
	Туре		Axial fan	
Ean	Motor output	W	46/	/53
Fall	Air flow rate(high)	m³/h	m³/h 2100	
	Speed(high/low)	rpm	850/300	
Heat	Туре		ML fin- Φ 7HI-HX tube	
exchanger	Row*stage*fitch		2.5*24*1.4	

TECHNICAL SPECIFICATIONS-OTHERS					
Refrigerant	Refrigerant type		R	R32	
circuit	Refrigerant charge		KG	1.2	
Circuit	Refrigerant control		EX	EXV	
Dining connecti	000	liquid	mm	Ф6.35	
(oxtornal diama	Piping connections	gas	mm	Ф9.52	
(external diame		drain	mm	Φ17	
Heat insulation ty	at insulation type Both liquid and Gas pipes			nd Gas pipes	
Max. piping Length		m	15		
Max. Level Differ	rence		m	10	
Chargeless		m	10		
Amount of Additional Charge of Refrigerant		g/m	20		
International Pro	tection degree		IP	24	

Note: the data are based on the conditions shown in the table below

cooling	heating	Piping length
Indoor: 27°CDB/19°CWB	Indoor:20°CDB	500
Outdoor: 35°CDB/24°CWB	Outdoor: 7℃DB/6℃WB	511

Conversation formulae
Kcal/h= KW×860
Btu/h= KW×3414
cfm=m³/min×35.3

3. Sensors list

type	Description	Qty
Ambient sensor Defrosting sensor Discharging sensor	Its used for detecting temperature of outdoor side Its used for controlling outdoor defrosting at heating mode Its used for compressor in case of over-heat	3 in 1
Suction sensor	Its used for detecting suction pipe temperature of compressor to adjust gas flowing	1

4. Pinping diagrams

Cooling mode



Heating mode



5. Operation range



6.PCB Diagram

Haier

Connectors

PCB (1) (Outdoor Control PCB)

- 1) CN1, CN2 Connector for power N and L
- 2) CN3 Connector for ground
- 3) CN23 Connector for DC POWER 15Vand 5V to the module board
- 4) CN9, CN10 Connector for CN2, CN1 on the module board
- 5) CN22 Connector for fan motor
- 6) CN11 Connector for four way valve coil
- 7) CN17, CN47 Connector for thermistors
- 8) CN24 Connector for communicate between the control board and the module board
- 9) CN26, CN25 Connector to P and N of the module board
- 10) CN36 Connector for communicate between indoor and outdoor unit
- 11) CN15 Connector for electric expansion valves
- 12) CN50 Connector for DRED-control
- 13) CN45 Connector for heating- protect wire of terminal block

Other Designations

- 1) FUSE 1, (25A, 250VAC); FUSE 2(3.15A, 250VAC)
- 2) LED 1 Keep light representative normal, if keep flash interval representative trouble Alarm3) RV1, RV2, RV3 Varistor

PCB (2) (Module PCB)

- CN10 Connector for the DC power 5V and 15V form the control PCB
- CN11 Connector for communicate between the control board and the module board
- P (CN1), N (CN5) Connector for capacitance board
- LI (CN7), LO (CN6) Connector for reactor
- CN2, CN3, CN4 Connector for the U, V, W wire of the compressor







PCB (2)

Wiring diagrams



7. Functions and Control

7.1 Main functions and control specification

7.1.1 The operation frequency of outdoor unit and its control

7.1.1.1 The operation frequency control of compressor

The operation frequency scope of compressor:

Mode	Minimun operation frequency	Maximun operation frequency
Heating	20Hz	118Hz
Refrigeration	20 Hz	90Hz

7.1.1.2 The starting of compressor

When the compressor is started for the first time, it must be kept under the conditions of 58Hz,88Hz for one minute (the overheating protection of the outdoor unit air-blowing temperature, immediately decrease the frequency when the compressor is overflowing and releasing the pressure), then it can be operated towards the target frequency. When the machine runs normally, there's no such process. After starting the compressor for operation, the compressor should run according to the calculated frequency, and every determined frequency for protection should be prior to the calculated frequency.

7.1.1.3 The speeds of increasing or decreasing the frequency of the compressor

The speed of increasing or decreasing the frequency rapidly 1	1HZ/second
The speed of increasing or decreasing the frequency slowly 2	1HZ/10seconds

7.1.1.4 The calculation of the compressor's frequency

1). The minimum/maximum frequency limitation

A. While refrigerating: F - M A X - r is the maximum operation frequency of the compressor; F - M

 $\ensuremath{\mathsf{IN-r}}$ is the minimum operation frequency of the compressor.

B. While heating: F - MAX - d is the maximum operation frequency of the compressor; F - MIN - d is the minimum operation frequency of the compressor.

1), The frequency limitation which is affected by the environment temperature.

Heating mode:

Serial No.	Temperature scope	Frequency limitation
1	Wh_c<-12	Max_hz8 117 HZ
2	Wh_c<-8	Max_hz7 117 HZ
3	Wh_c<-2	Max_hz4 117 HZ
4	Wh_c<5	Max_hz5 99 HZ
5	Wh_c<10	Max_hz1 90 HZ
6	Wh_c<17	Max_hz2 72 HZ
7	Wh_c<20	Max_hz2 62 HZ
8	Wh_c≥20	Max_hz6 45 HZ

Remarks: the above are the maximum frequency limitations of the complete appliance which are affected by the environment, and they have nothing to do with the ability of the indoor unit.

Refrigeration/dehumidification mode::

Serial No.	Temperature scope	Frequency limitation
1	Wh_c<16	Max_hz1 38 HZ
1	Wh_c<22	Max_hz1 44 HZ
1	Wh_c<28	Max_hz1 55 HZ

2	Wh_c<32	Max_hz2 74 HZ
3	Wh_c≥40	Max_hz3 90 HZ
4	Wh_c<48	Max_hz4 68 HZ
5	Wh_c≥48	Max_hz5 60 HZ

Remarks: the above are not only the maximum frequency limitations of the complete appliance which are affected by the environment, but also the maximum ability limitation of the system. When the starting ability is not the maximum, its maximum frequency limitation is calculated by the following equations:

The frequency limitation which is affected by the temperature and under the condition of actual ability=the actural running system ability*the maximum frequency which is limited by the temperature and under the condition of maximum ability/the maximum designing ability of the system

 $\Delta T=\Sigma (\Delta Ti^*Pi) / \Sigma Pi (\Delta Ti=|Tst_i-Tnh_i the indoor environment temperature|; Pi=i the ability of the indoor unit)$

Refrigeration/dehumidification:

Δ Τ	<1	=1	=2	=3	≥4
The percentage of the	70%	80%	85%	90%	100%
rated frequency P					

Heating mode:

ΔT	<1	=1	=2	=3	≥4
The percentage of the	70%	80%	85%	90%	100%
rated frequency P					

 $\mathsf{K}\text{=}\,\Sigma\,\mathsf{K}\text{i}/\mathsf{the}$ number of running machines

The indoor set airflow	Low	Medium	High	Strong	Quiet	Healthy
speed						airflow
The percentage of the	80%	90%	100%	110%	70%	65%
rated frequency Ki						

The calculation of the actual output frequency: when there is no healthy airflow: $F = F-ED^* \times P \times K$ When the healthy airflow has been set: $F = F-ED^* \times P \times K$ (airflow speed) $\times K$ (healthy airflow) When refrigerating, it is needed to satisfy F - MIN - d < F < F - MAX - dWhen heating, it is needed to satisfy F - MIN - r < F < F - MAX - r

7.1.2: The outdoor fan control (exchange fan)

When the fan is changed among every airflow speed (including stop blowing), in order to avoid the airflow speed from skipping frequently, it must be kept under each mode for over 30 seconds, and then it can be changed to another mode (when refrigerating, the time is changed to 15 seconds).

7.1.2.1: The outdoor fan control when refrigerating or dehumidifying



according to the temperature conditions of the outdoor environment.						
Tao (°C)	Tao <22℃	22℃5< Tao <29℃5	Tao≥29℃5			
Cool/Dry	Level 3	Level 5	Level 7			
Tao (°C)	Tao <10 °C	10°C< Tao <16°C	Tao≥16℃			
Heat	Level 7	Level 5	Level 3			

During the compressor is started for 3 seconds, the outdoor fan is controlled the airflow speed according to the temperature conditions of the outdoor environment.

After the compressor is started for 3 seconds, the outdoor fan is controlled the airflow speed according to the temperature conditions of the outdoor environment and frequency of compressor.

Frequency c	of cooling mode (Hz)	<51	51∽70	≥70	
	≤22	Level 3	Level 5	Level 6	
Tao (°C)	22 ∽29	Level 4	Level 6	Level 7	
	≥29	Level 7			

Frequency of heat mode (Hz)		<51	51∽90	≥90
Tao (°C)	≤10	Level 5	Level 7	Level 7
	10∽16	Level 4	Level 5	Level 5
	>16	Level 2		

7.1.3: The control of the outdoor electronic expansion valve

When starting the compressor: the opening size of the valve must be guaranteed to have entered into the standard opening size, and then the compressor can be started.

When refrigeration is in vain (the machine is shut down or is in the state of retrograde operation), the opening size of the expansion valve of the indoor unit is 5 steps;

When heating is in vain, the opening size of the expansion valve of the indoor unit is 55 steps;

When the outdoor unit is shut down, the valve is opened completely for 2 minutes, and then begin initialization.

The scope of refrigerationg valve 90-----480 steps

The scope of heating valve 60-----480 steps

The valves are adjusted according to the degree of superheat —SHa, \triangle SHa.

7.1.4: Four way control

For the details of defrosting four-way valve control, see the defrosting process.

Four way working in other ways:

Under the mode of heating, open the four-way valve, when the compressor is not started or changed to non-heating mode, make sure the compressor is stoped for 2 minutes, and then close the four-way valve.



7.1.5 : Protection function

7.1.5.1: TTC high temperature-preventing protection

Once the machine is started, it can run TTC overheating protection of air-blowing, but air-blowing sensor malfunction must alarm after 4 minutes during which the compressor is started (during the course of self-detection, there's no such limitation)

Sensor detection methods: 100 times (one cycle of procedure run is one time, and about 5ms, detection method for each time: continuously sampling for 8 times, then order them and take the mean value of the middle 2 values), take the mean value.



TTC>=115℃ lasts for 20 seconds. Overheating protection of air-blowing, alarm malfunction to the indoor, others don't last.

7.1.5.2: TC high temperature-preventing control of the indoor heating unit

Tpg_indoor is the highest value of the effective indoor unit (start it and it is in accord with the running state). The indoor heat exchanger sensor tests the temperature of the indoor heat exchanger. If the temperature is higher than 48°C, decrease the rotate speed of the compressor and do the high temperature-preventing protection of the indoor heat exchanger; if the temperature of the indoor heat exchanger is lower than 45°C, recover to the normal control.



N: Decreasing at the speed of 1HZ/1second

P: Decreasing at the speed of 1Hz/10seconds

Q: Continue to keep the last-time instruction cycle

R: Increasing at the speed of 1Hz/10seconds

Remarks: the outdoor unit

7.1.5.3: The protection function of AC current:

During the starting process of the compressor, if the AC current is greater than 12A, the frequency of the compressor decreases at the speed of 1HZ/second.

During the starting process of the compressor, if the AC current is greater than 11A, the frequency of the compressor decreases at the speed of 0.1HZ/second.

During the starting process of the compressor, if the AC current is greater than 10A, the frequency of the compressor increases at the prohibited speed.

During the starting process of the compressor, if the AC current is greater than 9A, the frequency of the compressor increases at the speed of no faster than 0.1HZ/second.

Remarks: when the outdoor temperature is high, there's compensation for AC current protection.

 $^{(1)}$ When the outdoor environment temperature is higher than 40 $^\circ\!C$, AC current protection value decreases by 1.5A

(2) When the outdoor environment temperature is higher than 50 $^\circ\!\mathrm{C}$,AC current protection value decreases by 3.5A

7.1.5.4: Antifreezing protection of the indoor heat exchanger

When refrigerating/heating, prevent freezing.

Tpg_indoor is the minimum value of the effective indoor unit (start it and it is in accord with the running state).



When Tpg_indoor \langle ice_temp_1 $^{\circ}$ C, the frequency of the compressor decreases at the speed of 1HZ/1second. When Tpg_indoor \langle ice_temp_2 $^{\circ}$ C, the frequency of the compressor decreases at the speed of 1HZ/10seconds.

When Tpg_indoor begins to rise again, and ice_temp_2 \leq Tpg_indoor \leq ice_temp_3 $^{\circ}$ C, the frequency of the compressor doesn't change.

When ice_temp_3 $\langle Tpg_indoor \langle ice_temp_4^{\circ}C \rangle$, the frequency of the compressor increases at the speed of 1HZ/10seconds.

For example, Tpg_indoor $\leq 0^{\circ}$ C, last for 2 minutes, and then the outdoor unit will stop, and report underload malfunction, but don't send malfunction report to the indoor.

The compressor stops for more than 3 minutes, Tpg_indoor> ice_temp_4 °C, the compressor recovers.

7.1.5.5: Temperature protection of the outdoor refrigerating coil

When the defrosting temperature and the sensor's temperature are higher than 68°C, the frequency of the compressor decreases 1hz/10seconds. Keep the frequency until it decreases to the lowest frequency. When the temperatures are lower than 68°C and higher than 61°C, keep the frequency of the compressor. When the temperatures are lower than 61°C, relieve the defrosting temperature protection.

7.2 Value of Thermistor

7.2.1 Outdoor Unit

Ambient Sensor, Defrosting Sensor, Pipe sensor

R25°C=10K $\Omega \pm 3\%$ B25°C/50°C=3700K $\pm 3\%$

Temp.(℃)	Max.(KΩ)	Normal(KΩ)	Min.(KΩ)	Tolerar	nce(℃)
-30	165.2170	147.9497	132.3678	-1.94	1.75
-29	155.5754	139.5600	125.0806	-1.93	1.74
-28	146.5609	131.7022	118.2434	-1.91	1.73
-27	138.1285	124.3392	111.8256	-1.89	1.71

Functions and control

-26	130.2371	117.4366	105.7989	-1.87	1.70
-25	122.8484	110.9627	100.1367	-1.85	1.69
-24	115.9272	104.8882	94.8149	-1.83	1.67
-23	109.4410	99.1858	89.8106	-1.81	1.66
-22	103.3598	93.8305	85.1031	-1.80	1.64
-21	97.6556	88.7989	80.6728	-1.78	1.63
-20	92.3028	84.0695	76.5017	-1.76	1.62
-19	87.2775	79.6222	72.5729	-1.74	1.60
-18	82.5577	75.4384	68.8710	-1.72	1.59
-17	78.1230	71.5010	65.3815	-1.70	1.57
-16	73.9543	67.7939	62.0907	-1.68	1.55
-15	70.0342	64.3023	58.9863	-1.66	1.54
-14	66.3463	61.0123	56.0565	-1.64	1.52
-13	62.8755	57.9110	53.2905	-1.62	1.51
-12	59.6076	54.9866	50.6781	-1.60	1.49
-11	56.5296	52.2278	48.2099	-1.58	1.47
-10	53.6294	49.6244	45.8771	-1.56	1.46
-9	50.8956	47.1666	43.6714	-1.54	1.44
-8	48.3178	44.8454	41.5851	-1.51	1.42
-7	45.8860	42.6525	39.6112	-1.49	1.40
-6	43.5912	40.5800	37.7429	-1.47	1.39
-5	41.4249	38.6207	35.9739	-1.45	1.37
-4	39.3792	36.7676	34.2983	-1.43	1.35
-3	37.4465	35.0144	32.7108	-1.41	1.33
-2	35.6202	33.3552	31.2062	-1.38	1.31
-1	33.8936	31.7844	29.7796	-1.36	1.29
0	32.2608	30.2968	28.4267	-1.34	1.28
1	30.7162	28.8875	27.1431	-1.32	1.26
2	29.2545	27.5519	25.9250	-1.29	1.24
3	27.8708	26.2858	24.7686	-1.27	1.22
4	26.5605	25.0851	23.6704	-1.25	1.20
5	25.3193	23.9462	22.6273	-1.23	1.18
6	24.1432	22.8656	21.6361	-1.20	1.16
7	23.0284	21.8398	20.6939	-1.18	1.14
8	21.9714	20.8659	19.7982	-1.15	1.12
9	20.9688	19.9409	18.9463	-1.13	1.09
10	20.0176	19.0621	18.1358	-1.11	1.07
11	19.1149	18.2270	17.3646	-1.08	1.05
12	18.2580	17.4331	16.6305	-1.06	1.03
13	17.4442	16.6782	15.9315	-1.03	1.01
14	16.6711	15.9601	15.2657	-1.01	0.99
15	15.9366	15.2770	14.6315	-0.98	0.96
16	15.2385	14.6268	14.0271	-0.96	0.94
17	14.5748	14.0079	13.4510	-0.93	0.92
18	13.9436	13.4185	12.9017	-0.91	0.90

Haier

Functions and control

19	13.3431	12.8572	12.3778	-0.88	0.87
20	12.7718	12.3223	11.8780	-0.86	0.85
21	12.2280	11.8126	11.4011	-0.83	0.83
22	11.7102	11.3267	10.9459	-0.81	0.80
23	11.2172	10.8634	10.5114	-0.78	0.78
24	10.7475	10.4216	10.0964	-0.75	0.75
25	10.3000	10.0000	9.7000	-0.75	0.75
26	9.8975	9.5974	9.2980	-0.76	0.76
27	9.5129	9.2132	8.9148	-0.80	0.80
28	9.1454	8.8465	8.5496	-0.84	0.83
29	8.7942	8.4964	8.2013	-0.87	0.86
30	8.4583	8.1621	7.8691	-0.91	0.90
31	8.1371	7.8428	7.5522	-0.95	0.93
32	7.8299	7.5377	7.2498	-0.98	0.97
33	7.5359	7.2461	6.9611	-1.02	1.00
34	7.2546	6.9673	6.6854	-1.06	1.04
35	6.9852	6.7008	6.4222	-1.10	1.07
36	6.7273	6.4459	6.1707	-1.13	1.11
37	6.4803	6.2021	5.9304	-1.17	1.14
38	6.2437	5.9687	5.7007	-1.21	1.18
39	6.0170	5.7454	5.4812	-1.25	1.22
40	5.7997	5.5316	5.2712	-1.29	1.25
41	5.5914	5.3269	5.0704	-1.33	1.29
42	5.3916	5.1308	4.8783	-1.37	1.33
43	5.2001	4.9430	4.6944	-1.41	1.36
44	5.0163	4.7630	4.5185	-1.45	1.40
45	4.8400	4.5905	4.3500	-1.49	1.44
46	4.6708	4.4252	4.1887	-1.53	1.47
47	4.5083	4.2666	4.0342	-1.57	1.51
48	4.3524	4.1145	3.8862	-1.61	1.55
49	4.2026	3.9686	3.7443	-1.65	1.59
50	4.0588	3.8287	3.6084	-1.70	1.62
51	3.9206	3.6943	3.4780	-1.74	1.66
52	3.7878	3.5654	3.3531	-1.78	1.70
53	3.6601	3.4416	3.2332	-1.82	1.74
54	3.5374	3.3227	3.1183	-1.87	1.78
55	3.4195	3.2085	3.0079	-1.91	1.82
56	3.3060	3.0989	2.9021	-1.95	1.85
57	3.1969	2.9935	2.8005	-2.00	1.89
58	3.0919	2.8922	2.7029	-2.04	1.93
59	2.9909	2.7948	2.6092	-2.08	1.97
60	2.8936	2.7012	2.5193	-2.13	2.01
61	2.8000	2.6112	2.4328	-2.17	2.05
62	2.7099	2.5246	2.3498	-2.22	2.09
63	2.6232	2.4413	2.2700	-2.26	2.13

Haier

Haier Functions and control 2.5396 2.3611 2.1932 2.17 64 -2.31 2.4591 2.2840 2.1195 -2.36 2.21 65 2.3815 2.2098 2.0486 -2.40 2.25 66 2.3068 2.1383 1.9803 -2.45 2.29 67 2.2347 2.0695 1.9147 -2.49 2.34 68 69 2.1652 2.0032 1.8516 -2.54 2.38 70 2.0983 1.9393 1.7908 -2.59 2.42 71 2.0337 1.8778 1.7324 -2.63 2.46 72 1.9714 1.8186 1.6761 -2.68 2.50 73 1.9113 1.7614 1.6219 -2.73 2.54 1.7064 1.5697 74 1.8533 -2.78 2.58 75 1.7974 1.6533 1.5194 -2.83 2.63 1.7434 1.6021 1.4710 -2.88 2.67 76 77 1.5528 1.4243 -2.92 2.71 1.6913 1.5051 1.3794 2.75 78 1.6409 -2.97 2.80 79 1.5923 1.4592 1.3360 -3.02 80 1.5454 1.4149 1.2942 -3.07 2.84 1.2540 2.88 81 1.5000 1.3721 -3.12 1.4562 1.3308 1.2151 2.93 82 -3.17 83 1.4139 1.2910 1.1776 -3.22 2.97 -3.27 84 1.3730 1.2525 1.1415 3.01 85 1.3335 1.2153 1.1066 -3.32 3.06 86 1.2953 1.1794 1.0730 -3.38 3.10 87 1.2583 1.1448 1.0405 3.15 -3.43 88 1.2226 1.1113 1.0092 -3.48 3.19 1.0789 0.9789 -3.53 3.24 89 1.1880 1.0476 0.9497 3.28 90 1.1546 -3.58 91 1.1223 1.0174 0.9215 -3.64 3.33 0.9882 3.37 92 1.0910 0.8942 -3.69 0.9599 3.42 93 1.0607 0.8679 -3.74 3.46 94 1.0314 0.9326 0.8424 -3.80 95 1.0030 0.9061 0.8179 -3.85 3.51 0.8806 3.55 0.9756 0.7941 -3.90 96 0.8558 0.7711 -3.96 0.9490 3.60 97 0.9232 0.8319 0.7489 -4.01 3.64 98 99 0.8983 0.8088 0.7275 -4.07 3.69 3.74 100 0.8741 0.7863 0.7067 -4.12 101 0.8507 0.7646 0.6867 -4.18 3.78 102 0.8281 0.7436 0.6672 -4.23 3.83 0.7233 -4.29 3.88 103 0.8061 0.6484 0.7848 0.7036 0.6303 -4.34 104 3.92 0.7641 0.6845 0.6127 3.97 105 -4.40 0.7441 0.6661 0.5957 -4.46 4.02 106 107 0.7247 0.6482 0.5792 -4.51 4.07 108 0.7059 0.6308 0.5632 -4.57 4.12

Haier

Functions and control

109	0.6877	0.6140	0.5478	-4.63	4.16
110	0.6700	0.5977	0.5328	-4.69	4.21
111	0.6528	0.5820	0.5183	-4.74	4.26
112	0.6361	0.5667	0.5043	-4.80	4.31
113	0.6200	0.5518	0.4907	-4.86	4.36
114	0.6043	0.5374	0.4775	-4.92	4.41
115	0.5891	0.5235	0.4648	-4.98	4.45
116	0.5743	0.5100	0.4524	-5.04	4.50
117	0.5600	0.4968	0.4404	-5.10	4.55
118	0.5460	0.4841	0.4288	-5.16	4.60
119	0.5325	0.4717	0.4175	-5.22	4.65
120	0.5194	0.4597	0.4066	-5.28	4.70

Discharging Sensor

R80°C=50K $\Omega\pm$ 3%

B25/80°C=4450K±3%

Temp.((℃))	Max.(KΩ)	Normal(KΩ)	Min.(KΩ)	Tolerar	nce(℃)
-30	14646.0505	12061.7438	9924.4999	-2.96	2.45
-29	13654.1707	11267.8730	9290.2526	-2.95	2.44
-28	12735.8378	10531.3695	8700.6388	-2.93	2.44
-27	11885.1336	9847.7240	8152.2338	-2.92	2.43
-26	11096.6531	9212.8101	7641.8972	-2.91	2.42
-25	10365.4565	8622.8491	7166.7474	-2.90	2.42
-24	9687.0270	8074.3787	6724.1389	-2.88	2.41
-23	9057.2314	7564.2244	6311.6413	-2.87	2.41
-22	8472.2852	7089.4741	5927.0206	-2.86	2.40
-21	7928.7217	6647.4547	5568.2222	-2.84	2.39
-20	7423.3626	6235.7109	5233.3554	-2.83	2.39
-19	6953.2930	5851.9864	4920.6791	-2.82	2.38
-18	6515.8375	5494.2064	4628.5894	-2.80	2.37
-17	6108.5393	5160.4621	4355.6078	-2.79	2.37
-16	5729.1413	4848.9963	4100.3708	-2.77	2.36
-15	5375.5683	4558.1906	3861.6201	-2.76	2.35
-14	5045.9114	4286.5535	3638.1938	-2.75	2.34
-13	4738.4141	4032.7098	3429.0191	-2.73	2.34
-12	4451.4586	3795.3910	3233.1039	-2.72	2.33
-11	4183.5548	3573.4260	3049.5312	-2.70	2.32
-10	3933.3289	3365.7336	2877.4527	-2.69	2.31
-9	3699.5139	3171.3148	2716.0828	-2.67	2.30
-8	3480.9407	2989.2460	2564.6945	-2.66	2.29
-7	3276.5302	2818.6731	2422.6139	-2.64	2.28
-6	3085.2854	2658.8058	2289.2164	-2.63	2.28
-5	2906.2851	2508.9126	2163.9230	-2.61	2.27
-4	2738.6777	2368.3158	2046.1961	-2.60	2.26
-3	2581.6752	2236.3876	1935.5371	-2.58	2.25

Functions and control

-2	2434.5487	2112.5459	1831.4826	-2.56	2.24
-1	2296.6230	1996.2509	1733.6024	-2.55	2.23
0	2167.2730	1887.0018	1641.4966	-2.53	2.22
1	2045.9191	1784.3336	1554.7931	-2.52	2.21
2	1932.0242	1687.8144	1473.1460	-2.50	2.20
3	1825.0899	1597.0431	1396.2333	-2.48	2.19
4	1724.6540	1511.6468	1323.7551	-2.47	2.17
5	1630.2870	1431.2787	1255.4324	-2.45	2.16
6	1541.5904	1355.6163	1191.0048	-2.43	2.15
7	1458.1938	1284.3593	1130.2298	-2.41	2.14
8	1379.7528	1217.2282	1072.8813	-2.40	2.13
9	1305.9472	1153.9626	1018.7481	-2.38	2.12
10	1236.4792	1094.3200	967.6334	-2.36	2.11
11	1171.0715	1038.0743	919.3533	-2.35	2.09
12	1109.4661	985.0146	873.7359	-2.33	2.08
13	1051.4226	934.9440	830.6210	-2.31	2.07
14	996.7169	887.6792	789.8583	-2.29	2.06
15	945.1404	843.0486	751.3077	-2.27	2.04
16	896.4981	800.8922	714.8380	-2.26	2.03
17	850.6086	761.0603	680.3265	-2.24	2.02
18	807.3024	723.4134	647.6580	-2.22	2.00
19	766.4212	687.8205	616.7252	-2.20	1.99
20	727.8172	654.1596	587.4271	-2.18	1.98
21	691.3524	622.3161	559.6694	-2.16	1.96
22	656.8979	592.1831	533.3634	-2.14	1.95
23	624.3328	563.6604	508.4261	-2.12	1.93
24	593.5446	536.6540	484.7796	-2.10	1.92
25	564.4275	511.0760	462.3510	-2.09	1.90
26	536.9865	486.9352	441.1516	-2.07	1.89
27	511.0105	464.0500	421.0258	-2.05	1.87
28	486.4151	442.3499	401.9146	-2.03	1.86
29	463.1208	421.7683	383.7626	-2.01	1.84
30	441.0535	402.2430	366.5175	-1.99	1.83
31	420.1431	383.7151	350.1301	-1.97	1.81
32	400.3242	366.1295	334.5542	-1.95	1.80
33	381.5350	349.4341	319.7460	-1.93	1.78
34	363.7176	333.5801	305.6645	-1.90	1.76
35	346.8176	318.5216	292.2709	-1.88	1.75
36	330.7839	304.2151	279.5286	-1.86	1.73
37	315.5682	290.6199	267.4031	-1.84	1.71
38	301.1254	277.6976	255.8620	-1.82	1.70
39	287.4128	265.4119	244.8745	-1.80	1.68
40	274.3905	253.7288	234.4118	-1.78	1.66
41	262.0206	242.6161	224.4465	-1.76	1.64
42	250.2676	232.0436	214.9529	-1.74	1.63

Haier

Functions and control

43	239.0983	221.9825	205.9065	-1.71	1.61
44	228.4809	212.4060	197.2844	-1.69	1.59
45	218.3860	203.2887	189.0648	-1.67	1.57
46	208.7855	194.6066	181.2273	-1.65	1.55
47	199.6531	186.3369	173.7524	-1.63	1.54
48	190.9639	178.4584	166.6217	-1.60	1.52
49	182.6945	170.9508	159.8181	-1.58	1.50
50	174.8228	163.7951	153.3249	-1.56	1.48
51	167.3280	156.9733	147.1268	-1.53	1.46
52	160.1904	150.4683	141.2090	-1.51	1.44
53	153.3914	144.2641	135.5577	-1.49	1.42
54	146.9136	138.3454	130.1598	-1.47	1.40
55	140.7403	132.6980	125.0027	-1.44	1.38
56	134.8559	127.3081	120.0746	-1.42	1.36
57	129.2457	122.1630	115.3645	-1.40	1.34
58	123.8956	117.2504	110.8618	-1.37	1.32
59	118.7926	112.5589	106.5564	-1.35	1.30
60	113.9241	108.0776	102.4388	-1.32	1.28
61	109.2784	103.7961	98.5000	-1.30	1.26
62	104.8443	99.7046	94.7315	-1.28	1.23
63	100.6112	95.7939	91.1253	-1.25	1.21
64	96.5692	92.0553	87.6735	-1.23	1.19
65	92.7088	88.4805	84.3690	-1.20	1.17
66	89.0211	85.0614	81.2048	-1.18	1.15
67	85.4976	81.7908	78.1744	-1.15	1.12
68	82.1303	78.6615	75.2715	-1.13	1.10
69	78.9116	75.6668	72.4902	-1.10	1.08
70	75.8343	72.8004	69.8249	-1.08	1.06
71	72.8916	70.0561	67.2703	-1.05	1.03
72	70.0770	67.4283	64.8213	-1.03	1.01
73	67.3844	64.9115	62.4731	-1.00	0.99
74	64.8080	62.5006	60.2211	-0.98	0.96
75	62.3423	60.1906	58.0609	-0.95	0.94
76	59.9821	57.9770	55.9885	-0.92	0.92
77	57.7223	55.8552	53.9998	-0.90	0.89
78	55.5583	53.8210	52.0912	-0.87	0.87
79	53.4856	51.8706	50.2591	-0.85	0.84
80	51.5000	50.0000	48.5000	-0.85	0.84
81	49.7063	48.2057	46.7083	-0.85	0.85
82	47.9835	46.4842	44.9911	-0.89	0.89
83	46.3286	44.8323	43.3452	-0.93	0.92
84	44.7385	43.2468	41.7672	-0.96	0.95
85	43.2105	41.7248	40.2540	-1.00	0.99
86	41.7386	40.2604	38.7996	-1.03	1.02
87	40.3241	38.8545	37.4048	-1.07	1.06

Functions and control

88	38.9643	37.5045	36.0668	-1.11	1.09
89	37.6569	36.2078	34.7831	-1.14	1.13
90	36.3996	34.9622	33.5513	-1.18	1.16
91	35.1903	33.7653	32.3689	-1.22	1.19
92	34.0269	32.6151	31.2338	-1.26	1.23
93	32.9075	31.5096	30.1438	-1.30	1.27
94	31.8302	30.4467	29.0970	-1.33	1.30
95	30.7933	29.4246	28.0915	-1.37	1.34
96	29.7950	28.4417	27.1254	-1.41	1.37
97	28.8337	27.4961	26.1970	-1.45	1.41
98	27.9078	26.5864	25.3048	-1.49	1.44
99	27.0160	25.7110	24.4470	-1.53	1.48
100	26.1569	24.8685	23.6222	-1.57	1.52
101	25.3290	24.0574	22.8291	-1.61	1.55
102	24.5311	23.2765	22.0662	-1.65	1.59
103	23.7620	22.5245	21.3323	-1.69	1.63
104	23.0205	21.8002	20.6261	-1.73	1.66
105	22.3055	21.1025	19.9465	-1.77	1.70
106	21.6159	20.4303	19.2924	-1.81	1.74
107	20.9508	19.7825	18.6626	-1.85	1.77
108	20.3091	19.1582	18.0563	-1.89	1.81
109	19.6899	18.5564	17.4723	-1.93	1.85
110	19.0924	17.9761	16.9098	-1.98	1.89
111	18.5157	17.4166	16.3680	-2.02	1.93
112	17.9590	16.8769	15.8458	-2.06	1.96
113	17.4214	16.3564	15.3427	-2.10	2.00
114	16.9023	15.8542	14.8577	-2.15	2.04
115	16.4010	15.3696	14.3902	-2.19	2.08
116	15.9167	14.9020	13.9394	-2.23	2.12
117	15.4489	14.4506	13.5047	-2.27	2.16
118	14.9968	14.0149	13.0855	-2.32	2.19
119	14.5599	13.5942	12.6811	-2.36	2.23
120	14.1376	13.1879	12.2909	-2.41	2.27
121	13.7294	12.7955	11.9144	-2.45	2.31
122	13.3347	12.4165	11.5510	-2.50	2.35
123	12.9531	12.0503	11.2003	-2.54	2.39
124	12.5840	11.6965	10.8617	-2.58	2.43
125	12.2270	11.3545	10.5348	-2.63	2.47
126	11.8817	11.0240	10.2191	-2.68	2.51
127	11.5475	10.7046	9.9142	-2.72	2.55
128	11.2242	10.3957	9.6197	-2.77	2.59
129	10.9112	10.0970	9.3352	-2.81	2.63
130	10.6084	9.8082	9.0602	-2.86	2.67
131	10.3151	9.5288	8.7945	-2.91	2.71
132	10.0312	9.2586	8.5378	-2.95	2.75

Haier

Functions and control

133	9.7563	8.9971	8.2895	-3.00	2.80
134	9.4901	8.7441	8.0495	-3.05	2.84
135	9.2322	8.4993	7.8175	-3.09	2.88
136	8.9824	8.2623	7.5931	-3.14	2.92
137	8.7404	8.0329	7.3760	-3.19	2.96
138	8.5059	7.8108	7.1660	-3.24	3.00
139	8.2787	7.5958	6.9629	-3.29	3.04
140	8.0584	7.3875	6.7664	-3.33	3.09

8.Dimensional drawings



9.Center of gravity



10.Service Diagnosis

10.1.1 Caution for Diagnosis

The operation lamp flashes when any of the following errors is detected.

1. When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions, disabling equipment operation.

2.When a signal transmission error occurs between the indoor and outdoor units.In either case, conduct the diagnostic procedure described in the following pages.

10.1.2 Problem Symptoms and Measures

Symptom	Check Item	Details of Measure
None of the units	Check the power supply.	Check to make sure that the rated voltage is supplied.
operates	Check the indoor PCB	Check to make sure that the indoor PCB is broken
Operation sometimes stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation.
Equipment operates but does not cool, or does not heat (only for heat	Check for faulty operation of the electronic expansion valve.	Set the units to cooling operation, and compare the temperatures of the liquid side connection pipes of the connection section among rooms to check the opening and closing operation of the electronic expansion valves of the individual units.
pump)	Diagnosis by service port pressure and operating current.	Check for insufficient gas.
Large operating noise and vibrations	Check the installation condition.	Check to make sure that the required spaces for installation (specified in the Technical Guide, etc.) are provided.

10.2 Parameter of primary electronic appliance

NO	Name	Parameter	Picture
1	ELECTRIC EXPANSION VALVE	Rated voltage:12V Valve orifice:φ1.65MM Coil resistance 46±3.7Ω	yellow white rod proven blue orange red brown blue orange yellow white

10.3 Error Codes and Description indoor display

	Code indication					
	Indooi	r displaying panel code indication	Outdoor	fault description		
	Other display Only For 498 and 498A display (Red/Green Time Run □On ★ Flash ∎Off ,)		flash times)			
Indoor and Outdoor	E7	■ ■★	15	Communication fault between indoor and outdoor units		
	E1	★ ■■		Room temperature sensor failure		
Indoor Malfunction	E2	* 🗆		Heat-exchange sensor failure		
	E4	★ □★		Indoor EEPROM error		
	E14	■ □★		Indoor fan motor malfunction		
	F12	■★■	1	Outdoor EEPROM error		
	F1		2	The protection of IPM		
Outdoor Malfunction	F22	* ★ ■	3	Overcurrent protection of AC electricity for the outdoor model		
	F3	■★■	4	Communication fault between the IPM and outdoor PCB		
	F20	1	5	Compressor overload		
	F19	■ ★ □	6	Power voltage is too high or low		
	F27	/	7	Compressor blocked		
	F4	■★■	8	Overheat protection for Discharge temperature		
	F8	/	9	Outdoor DC fan motor fault		
	F21		10	Defrost temperature sensor failure		
	F7	■★■	11	Suction temperature sensor failure		
	F6		12	Ambient temperature sensor failure		
	F25	★□■	13	Discharge temperature sensor failure		
	F30		14	Suction temp of compressor is too high		
	F13		16	Less gas charge		
	F14		17	4-way-valve fault		
	F11	■★■	18	deviate from the normal for the compressor		
	F28	■★■	19	Loop of the station detect error		
	F2	■ ★ □	24	Overcurrent of the compressor		
	F23	■★□	25	Overcurrent protection for single-phase of the compressor		

10.3.1 Thermistor or Related Abnormality

Indoor display	E1: Room temperature sensor failure
	E2: Indoor pipe sensor failure

outdoor display	LED1	flash 10 times:	Defrost temperature sensor failure	
	LED1	flash 11 times:	Suction temperature sensor failure	Spare parts:
	LED1	flash 12 times:	Ambient temperature sensor failure	Sensors
	LED1	flash 13 times:	Discharge temperature sensor failure	


10.3.2 EEPROM abnormal

Indoor Display E4: indoor EEPROM error Outdoor display F12: Outdoor EEPROM error; Outdoor LED1 flash 1 times Spare parts: Indoor PCB Replace the indoor or outdoor PCB

10.3.3 Indoor AC fan motor malfunction



10.3.4 Outdoor DC fan motor fault

Outdoor display F8 LED1 flash 9 times





10.3.6 Over-current of the compressor





10.3.7 The communication faulbetween IPM and outdoor PCB





10.3.8 Power Supply Oveor under voltage fault



10.3.9 Overheat ProtectionFor Discharge Temperature



Haier Seivice diagnosis 10.3.10 The communication fault between indoor and outdoor Indoor display E7 Outdoor display LED1 flash 15 times Indoor checking process yes Whether the connect cable is Fix the connect cable bad or wrong connection. no Whether the indoor PCB yes Indoor PCB ok LED flashing regularly(3 times/seconds)? no Whether the indoor PCB yes Indoor PCB ok, need LED flashing as: check outdoor side. "Flash...Flash...On" and repeatedly? no Whether the voltage yes Indoor PCB ok, need L line between N line and C check outdoor side. line is 0~80VAC? This is a changeful value not a fixed. no Out oor terminal b Whether the voltage yes between N line and C Indoor PCB fault. line is a fixed value? no Whether the voltage yes Indoor PCB ok between L line and C line is 0~140VAC? This is a changeful value not a fixed. no

Haier

yes

yes

Outdoor PCB fault.

C line connection

fault, or wire broken.

If the voltage between L

no

The Indoor PCB led no

flash or off, and indoor

display OK?

line and C line is 0[~] 80VAC approx.

Seivice diagnosis





Outdoor checking process -5



L7805

Outdoor checking process -6

1. Check whether the L7805 is OK; The voltage between Pin1 & Pin2 is +12VDC The voltage between Pin2 & Pin3 is +5VDC

2. The voltage of Module Power socket between1 & 2 is approx DC5V,2 & 3 is approx DC15V







10.3.11 Compressor loss of synchronism detection

Outdoor Display F11 LED1 flash 18 times

The fault phenomenon is the compressor rotor demagnetization and couldn't reach the request frequency.

It is caused by the high exhaust temp or high running current. In this fault we suggest change the compressor. Spare parts: Compressor

10.3.12 Compressor position detection circuit fault

Outdoor Display F28 LED1 flash 19 times

This is caused by the compressor position detection circuit fault, this circuit is located on the power module.

This fault should change the power module.



11.Performence and curves diagrams --1U26JACFRA

11.1 Cooling capacity-temperature curves

performance curves										
cooling value-temerature table										
indoor temp.					outdoor temp	D				
DB/WB	10 ℃	15 ℃	20 ℃	25 ℃	30 ℃	35 ℃	38 ℃	40 ℃	43 ℃	
21/15℃	2497	2439	2343	2205	2340	2450	2365	2327	2042	
24/16 ℃	2597	2536	2437	2293	2434	2548	2459	2420	2156	
27/19 ℃	2700	2638	2534	2385	2531	2658	2558	2517	2246	
30/22 ℃	2808	2743	2636	2481	2633	2756	2660	2618	2341	
32/23 ℃	2921	2853	2741	2580	2738	2866	2766	2723	2435	
35/24 ℃	3038	2967	2851	2683	2847	2981	2877	2832	2503	



11.2 Cooling power consumption value- temperature curves

performance curves											
power consumption temp.table											
indoor temp.				(outdoor temp).					
DB/WB	10 ℃	15 ℃	20 ℃	25 ℃	30 ℃	35 ℃	38 ℃	40 ℃	43 ℃		
21/15℃	576	608	632	667	695	737	772	798	813		
24/16 ℃	598	625	648	681	716	758	790	814	828		
27/19 ℃	622	640	658	688	730	779	808	835	849		
30/22 ℃	643	660	685	712	751	800	842	863	877		
32/23 ℃	658	681	704	732	772	835	884	914	929		
35/24 ℃	671	702	738	775	793	856	898	938	945		



11.3 Cooling discharge pressure curves

performance curves								
	cooling discharge pressure.table							
outdoor temp. (humidity 46%)	indoor temp.							
DB/WB	21/15 ℃	21/15°C 27/19°C 35/24°C						
10 ℃	2009	2070	2194					
15 ℃	2058	2095	2221					
20 °C	2093	2148	2230					
25 ℃	2218	2252	2297					
30 ℃	2350	2457	2539					
35 ℃	2537	2622	2781					
38 °C	2751	2816	2993					
40 ℃	3024	3174	3339					
43 ℃	3388	3589	3905					



11.4 Cooling suction pressure curves

performance curves									
	cooling suction pressure.table								
outdoor temp. (humidity 46%)		indoor temp.							
DB/WB	21/15 ℃	27/19 ℃	35/24 ℃						
10 ℃	719	842	978						
15 ℃	727	850	988						
20 ℃	733	867	998						
25 ℃	772	876	1018						
30 ℃	813	922	1028						
35 ℃	821	932	1082						
38 ℃	865	960	1105						
40 ℃	951	1056	1215						
45 ℃	1046	1141	1324						



11.5 Heating capacity-temperature curves

performance curves								
	heating capacity and indoor/outdoor temp.table							
outdoor temp.		indoor temp.(humidity 46%)						
DB/WB	10 ℃	20 ℃	27 ℃					
-15 ℃	1874	1687	1505					
-10 ℃	2365	2126	1861					
-7/-8 ℃	2878	2606	2278					
2/1 ℃	3563	3173	2783					
7/6 ℃	3537	3323	2916					
12/11 ℃	3429	3006	2499					
18/16 ℃	2616	2369	2071					
24/20 ℃	2150	1932	1692					



11.6 Heating power consumption value- temperature curves

performance curves								
power consumption value-temp.table								
outdoor temp.		indoor temp.(humidity 46%	o)					
DB/WB	15 ℃	20 ℃	25 ℃					
-15℃	807	876	932					
-10 ℃	907	968	1029					
-7/-8 ℃	992	1092	1145					
2/1 ℃	1055	1147	1222					
7/6 ℃	942	1037	1088					
12/11 ℃	775	827	879					
18/16 ℃	620	661	703					
24/20 ℃	423	463	493					



11.7 Heating discharge pressure curves

performance curves									
	Heating discharge pressure.table								
outdoor temp. (humidity 46%)		indoor temp.							
DB/WB	10 ℃	20 °C	27 ℃						
−15 °C	2600	2764	2921						
−10 °C	2856	2980	3152						
-7/-8℃	3286	3411	3512						
2/1 ℃	3402	3698	3801						
7/6 ℃	3456	3590	3725						
12/11 ℃	3278	3482	3589						
18/16 ℃	3132	3273	3315						
24/20 ℃	2631	2782	2889						



11.8 Heating suction pressure curves

performance curves								
	heating suction pressure table							
outdoor temp. (humidity 46%)		indoor temp.						
DB/WB	10°C	20°C	27°C					
−15°C	352	393	413					
−10°C	406	437	456					
-7∕-8℃	502	543	562					
2/1°C	623	664	683					
7/6℃	759	800	819					
12/11℃	861	902	922					
18/16°C	1031	1072	1092					
24/20°C	1221	1262	1282					



11.Performence and curves diagrams-- (1U35JACFRA)

11.1 Cooling capacity-temperature curves

performance curves										
cooling value-temerature table										
indoor temp.					outdoor temp)				
DB/WB	10 ℃	15 ℃	20 ℃	25 ℃	30 ℃	35 ℃	38 ℃	40 ℃	43 ℃	
21/15 ℃	3201	3127	3004	2827	3000	3141	3032	2984	2536	
24/16 ℃	3329	3252	3124	2940	3120	3266	3153	3103	2638	
27/19 ℃	3462	3382	3249	3058	3245	3415	3279	3227	2743	
30/22 ℃	3601	3517	3379	3180	3375	3533	3410	3356	2853	
32/23 ℃	3745	3658	3514	3307	3510	3674	3547	3491	2967	
35/24 ℃	3894	3804	3655	3440	3650	3821	3688	3630	3086	



11.2 Cooling power consumption value- temperature curves

performance curves										
power consumption temp.table										
indoor temp.				(outdoor temp).				
DB/WB	10 ℃	15 ℃	20 ℃	25 ℃	30 ℃	35 ℃	38 ℃	40 ℃	43 ℃	
21/15 ℃	779	822	854	901	939	996	1043	1079	1099	
24/16 ℃	809	845	877	920	968	1024	1068	1100	1120	
27/19 ℃	841	866	890	930	987	1053	1093	1129	1149	
30/22 ℃	869	892	926	963	1015	1081	1138	1166	1186	
32/23 ℃	890	920	953	990	1043	1129	1195	1216	1226	
35/24 ℃	908	949	998	1048	1072	1157	1203	1238	1235	



11.3 Cooling discharge pressure curves

performance curves								
cooling discharge pressure.table								
outdoor temp. (humidity 46%)	indoor temp.							
DB/WB	21/15 ℃	27/19 ℃	35/24 ℃					
10 ℃	1948	2010	2131					
15 ℃	1933	2037	2152					
20 °C	2010	2064	2156					
25 ℃	2071	2144	2246					
30 °C	2269	2385	2486					
35 ℃	2405	2546	2713					
38 °C	2647	2734	2906					
40 °C	2957	3082	3242					
43 °C	3324	3484	3713					



11.4 Cooling suction pressure curves

performance curves								
cooling suction pressure.table								
outdoor temp. (humidity 46%)		indoor temp.						
DB/WB	21/15 ℃	21/15℃ 27/19℃ 35/24℃						
10 ℃	757	886	1029					
15 ℃	765	895	1040					
20 ℃	772	913	1050					
25 ℃	813	922	1072					
30 ℃	856	971	1082					
35 ℃	864	981	1139					
38 ℃	910	1011	1163					
40 ℃	1001	1112	1279					
43 ℃	1101	1201	1394					



11.5 Heating capacity-temperature curves

performance curves				
heating capacity and indoor/outdoor temp.table				
outdoor temp.	indoor temp.(humidity 46%)			
DB/WB	10 ℃	20 ℃	27 ℃	
- 15 ℃	2155	1940	1730	
-10 ℃	2719	2444	2140	
-7/-8 ℃	3308	2996	2619	
2/1 ℃	4176	3946	3452	
7/6 ℃	4120	3812	3325	
12/11 ℃	3932	3456	2873	
18/16 ℃	3008	2724	2381	
24/20 ℃	2471	2222	1945	



11.6 Heating power consumption value- temperature curves

performance curves				
power consumption value-temp.table				
outdoor temp.		indoor temp.(humidity 46%)		
DB/WB	15 ℃	20 ℃	25 ℃	
- 15 ℃	807	876	932	
-10 ℃	907	968	1029	
-7/-8 ℃	992	1092	1145	
2/1 ℃	1045	1137	1165	
7/6 ℃	942	1037	1088	
12/11 ℃	775	827	879	
18/16 ℃	620	661	703	
24/20 °C	423	463	493	



11.7 Heating discharge pressure curves

performance curves			
heating discharge pressure.table			
outdoor temp	indoor temp.		
DB/WB	10 ℃	20 °C	27 ℃
-15℃	2585	2764	2895
-10 ℃	2834	2980	3142
-7/-8 ℃	3272	3411	3554
2/1 ℃	3396	3698	3845
7/6 ℃	3407	3590	3768
12/11 ℃	3259	3482	3635
18/16 ℃	3128	3273	3375
24/20 °C	2601	2782	2867



11.8 Heating suction pressure curves

performance curves			
heating suction pressure.table			
outdoor temp	indoor temp.		
DB/WB	10 °C	20 °C	27 ℃
-15 ℃	345	385	405
-10 ℃	398	428	447
-7/-8 ℃	492	532	551
2/1 ℃	611	651	670
7/6 ℃	744	784	803
12/11 ℃	844	884	904
18/16 ℃	1011	1051	1071
24/20 ℃	1197	1237	1257



13 Circuit diagrams

13.1 Outdoor unit control board Circuit Diagrams





12 Circuit diagrams

12.1 Outdoor unit control board Circuit Diagrams





12.2 Module board Circuit Diagram



Sincere Forever

Haier Group

Haier Industrial Park, No.1, Haier Road

266101, Qingdao, China_

Http: //www.haier.com

Edited by : Zhen Lingyun Zhang Jing Signed by : Zhang Xianqiang Approved by: He Shiquan



Haier REMOVAL PROCEDURE

Wall Mounted Type DC Inverter FREE MATCH NEW40-Series SERIES:NEW40



Remove of front panel

Outdoor unit

Step		Procedure	Points
1.Featur	es		
1	Loosen the service cover screw and remove the service cover.		Be careful not to cut your finger by the fins of the heat exchanger



Step Procedure Points		Step Procedure Points	Step Procedure Points
2. Remov 1	ve the panels. Loosen the 7 screws and lift the top panel		
2.	Loosen the screws of the panel.		
3	Pull and remove the front panel.		


Remove the air filters and horizontal flap

Step		Procedure	Points
1	Loosen the fixting screws and remove The back protect net .		
2			
1	Loosen the fixting screws and remove the side panel.		



Remove the casing

Step		Procedure	Points
1	Loosen the fixting screws and remove the side panel.		
	Loosen the fixting screws and remove the cross beam.	· · ·	
2			

Step		Procedure	Points
3	Loosen the fixting screws remove the fan		
	Loosen the fixting screws and lift the fan motor.		



Release stepping motor (2type)

Step		Procedure	Points
1	Remove the fixing screws,then lift the fan motor bracket		
2	Cut down the and pull out the compressor and remove the		



Removal of Heat Exchanger

Step		Procedure	Points
	Loosen the marked fixing screws		
	Loosen the fixting hook and remove the heat exchanger		

Step		Procedure	Points
	Remove the fixing screws,then lift the heating pipe		
	Remove the fixing screws,then lift the valves	· · ·	

Step		Procedure	Points
	Remove the fixing screw,then lift the valve set		





Read the precautions in this manual carefully before operating the unit.



This appliance is filled with R32.

Keep this manual where the user can easily find it.

WARNING:

- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance must be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- The appliance must be installed, operated and stored in a room with a floor area larger than 3 m².
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mentao capabilities or lack of experience and knowledge if they have been given superivision or instruction concering use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The wiring method should be in line with the local wiring standard.
- All the cables shall have got the European authentication certificate. During installation, when the connecting cables break off, it must be assured that the grouding wire is the last one to be broken off. The explosion-proof breaker of the air conditioner should be all-pole switch. Distance between its two
- contacts should not be no less than 3mm. Such means for disconnection must be incorporated in the wiring.
- Make sure installation is done according to local wiring regulation by professional persons.
- Make sure ground connection is correct and reliable.
- A leakage explosion-proof breaker must be installed.
- Do not use a refrigerant other than the one indicated on the outdoor unit(R32) when installing, moving or repairing. Using other refrigerants may cause trouble or damage to the unit, and personal injury.



No fire source around the place of installation







Read operator' manual

Read technical manual

Operator' manual; operating instructions

Installation Manual of Room Air Conditioner



more than60cm Please be subject to the actual product purchased , the above picture is just for your reference.

Read this manual before installation

Explain sufficiently the operating means to the user according to this manual

(F) Heating insulating material

(A) Non-adhesive tape(B) Adhesive tape

C Saddle (L.S) with screws

Connecting electric cable

for indoor and outdoor

G Piping hole cover

E Drain hose

 \bigcirc



	Liquid pipe	[⊕] 6.35x0.8mm
FOR 09K 12K	Gas pipe	\oplus 9.52x0.8mm
	Liquid pipe	Φ 6.35x0.8mm
FUR ION	Gas pipe	↓ 12.7x0.8mm
FOR 24K	Liquid pipe	Ф 6.35x0.8mm
	Gas pipe	

Indoor unit

Fitting of the Mounting Plate and Positioning of the wall Hole

When the mounting plate is first fixed

 Carry out, based on the neighboring pillars or lintels, a proper leveling for the plate to be fixed against the wall, then temporarily fasten the plate with one steel nail.

- Make sure once more the proper level of the plate, by hanging a thread with a weight from the central top of the plate, then fasten securely the plate with the attachment steel nail.
- 3. Find the wall hole location A using a measuring tape





When the mounting plate is fixed side bar and lintel Fix to side bar and lintel a mounting bar, Which is separately sold, and then fasten the plate to the fixed mounting bar. • Refer to the previous article, "When the mounting plate is first fixed ", for the position of wall hole. 2 Making a Hole on the Wall and Fitting the Piping Hole Cover • Make a hole of 60 mm in diameter, slightly descending to outside the wall. • Install piping hole cover and seal it off with putty after installation Wall hole Ø60mm Thickness of wall Outdoor side G Piping hole pipe (Section of wall hole) Indoor side Installation of the Indoor Unit Drawing of pipe [Rear piping]

Draw pipes and the drain hose, then fasten them with the adhesive tape

- [Left · Left-rear piping]
 - In case of left side piping, cut away, with a nipper, the lid for left piping.
 - In case of left-rear piping, bend the pipes according to the piping direction to the mark of hole for left-rear piping which is marked on heat insulation materials.

1. Insert the drain hose into the dent of heat insulation materials of indoor unit.

 Insert the indoor/outdoor electric cable from backside of indoor unit, and pull it out on the front side, then connect, them

Coat the flaring seal face with refrigerant oil and connect pipes.
 Cover the connection part with heat insulation materials closely, and make sure





Fix with adhesive tape

 Indoor/outdoor electric cable and drain hose must be bound with refrigerant piping by protecting tape.

[Other direction piping]

- Cut away, with a nipper, the lid for piping according to the piping direction and then bend the pipe according to theposition of wall hole. When bending, be careful not to crash pipes.
- Connect beforehand the indoor/outdoor electric cable, and then pull out the connected to the heat insulation of connecting part specially.

Fixing the indoor unit body

• Hang surely the unit body onto the upper notches of the mounting plate. Move the body from side to side to verify its secure fixing.



mounting plate

• In order to fix the body onto the mounting plate,hold up the body aslant from the underside and then put it down perpendicularly.



• When you unload the indoor unit, please use your hand to arise the body to leave agraffe, then lift the bottom of the body outward slightly and lift the unit aslant until it leaves the mounting plate.

agraffe mounting plate

Connecting the indoor/outdoor Electric Cable

Removing the wiring cover

Remove terminal cover at right bottom corner of indoor unit, then take off wiring cover by removing its screws.

When connecting the cable after installing the indoor unit

- 1. Insert from outside the room cable into left side of the wall hole, in which the pipe has already existed.
- 2. Pull out the cable on the front side, and connect the cable making a loop.

When connecting the cable before installing the indoor unit

- Insert the cable from the back side of the unit, then pull it out on the front side.
- Loosen the screws and insert the cable ends fully into terminal block, then tighten the screws
- Pull the cable slightly to make sure the cables have been properly inserted and tightened
- After the cable connection, never fail to fasten the connected cable with the wiring cover.



Note:

When connecting the cable, confirm the terminal number of indoor and outdoor units carefully. If wiring is not correct, proper operation can not be carried out and will cause defect.

> ≥4G1.0mm Connecting wiring

- 1. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similar qualified person. The type of connecting wire is H05RN-F or H07RN-F.
- 2. If the fuse on PC board is broken please change it with the type of T. 3.15A/250V.
- 3. The wiring method should be in line with the local wiring standard.
- 4. After installation, the power plug should be easily reached.
- 5. A breaker should be incorporated into fixed wiring. The breaker should be all-pole switch and the distance between its two contacts should be not less than 3mm

6.Please consult your reseller and/or installer to determine if you have a DRED appliance. Connect output from your home's electricity power meter (where available) to the RJ45 connector on the outdoor unit, as shown. (This function is unavailable on some models.)



Outdoor unit

Installation of Outdoor Unit

Install according to Drawing for the installation of indoor and outdoor units

Connection of pipes

- To bend a pipe, give the roundness as large as possible not to crush the pipe, and the bending radius should be 30 to 40 mm or longer.
- Connecting the pipe of gas side first makes working easier.
- The connection pipe is specialized for R410A



Spanner Torque wrench

Pipe Diameter(ø)	Fastening torque
Liquid side6.35mm(1/4")	18N.m
Liquid/Gas side9.52mm(3/8")	42 N.m
Gas side 12.7mm(1/2")	55N.m
Gas side 15.88mm(5/8")	60 N.m

Be careful that matters, such as wastes of sands, etc. shall not enter the pipe. The standard pipe length is 5m. If it is over 7m, the function of the unit will be affected. If the pipe has to be lengthened, the refrigerant should be charged, according to 20 g/m. But the charge of refrigerant must be conducted by professional air conditioner engineer. Before adding additional refrigerant, perform air purging from the refrigerant pipes and indoor unit using a vacuum pump, then charge additional refrigerant.



Connection

- Use the same method on indoor unit. Loosen the screws on terminal block and insert the plugs fully into terminal block, then tighten the screws
- Insert the cable according to terminal number in the same manner as the indoor unit
- If wiring is not correct, proper operation can not be carried out and controller
- may be damaged.
 Fix the cable with a clamp.

Attaching Drain-Elbow

If the drain-elbow is used. please attach it as figure. (Note: Only for heat pump unit.)



Purging Method: To use vacuum pump

- 1. Detach the service port's cap of 3-way valve, the valve rod's cap for 2-way valve and 3-way's, connect the service port into the projection of charge hose (low) for gaugemanifold. Then connect the projection of charge hose (center) for gaugemanifold into vacuum pump.
- 2. Open the handle at low in gaugemanifold, operate vacuum pump. If the scalemoves of gause (low) reach vacuum condition in a moment, check 1. again.
- 3. Vacuumize for over 15min. And check the level gauge which should read -0.1MPa (76 cm Hg) at low pressure side. After the completion of vacuumizing, close the handle 'Lo' in gaugemanifold and stop the operation of the vacuum pump. Check condition of the scale and hold it for 1-2min. If the scale-moves back in spite of tightening, make flaring work again, the return to the beginning of 3 .
- 4. Open the valve rod for the 2-way valve to an angle of anticlockwise 90 degrees. After 6 seconds, close the 2-way valve and make the inspection of gas leakage.





is carried out surely to outdoor. In case that the attached drain hose is in a room, please apply heat insulation to

In case that the attached drain hose is in a room, please apply heat insulation to it without fail.

Refrigerant charge label



This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent into the atmosphere. Refrigerant type:R32

GWP* value:675

GWP=global warming potential

Please fill in with indelible ink,

- 1 the factory refrigerant charge of the product
- 2 the additional refrigerant amount charged in the field and • 1+2 the total refrigerant charge

on the refrigerant charge label supplied with the product.

The filled out label must be adhered in the proximity of the product charging port (e.g. onto the inside of the stop value cover).

A contains fluorinated greenhouse gases covered by the Kyoto Protocol

- B factory refrigerant charge of the product: see unit name plate
- C additional refrigerant amount charged in the field
- D total refrigerant charge
- E outdoor unit
- F refrigerant cylinder and manifold for charging

Check for Installation and Test Run

Please kindly explain to our customers how to operate through the instruction manual.

Check Items for Test Run

Put check mark in boxes

- Gas leak from pipe connecting?
- Heat insulation of pipe connecting?
- Are the connecting wirings of indoor and outdoor firmly inserted to the terminal block?
- Is the connecting wiring of indoor and outdoor firmly fixed?
- Is drainage securely carried out?
- Is the earth line securely connected?
- Is the indoor unit securely fixed?
- □Is power source voltage abided by the code?
- Is there any noise? Is the lamp normally lighting?
- □ Are cooling and heating (when in heat pump) performed normally?
- Is the operation of room temperature regulator normal?