

Dishwasher

White



With Delay Start function so you can get the dishes done at your convenience. Auto Wash setting optimises water and energy consumption for a more sustainable wash.

- AUTO wash to optimise your water & energy usage
- Height adjustable upper basket
- Lock function - to stop accidental opening
- Soft touch LED controls
- Water rating (WELS) - 4.5 star

DIMENSIONS

Height	850 mm
Width	598 mm
Depth	598 mm

FEATURES & BENEFITS

Auto Wash



Adjustable Upper Basket

Create room to fit larger dishes up to 290mm tall in the lower basket

Safety Lock



Soft Touch LED Controls

Easy to use and keep clean

SPECIFICATIONS

Capacity and Loading

Place settings	13
----------------	-----------

Consumption

Energy Consumption (Normal Eco)	285 kWh
Energy rating	3 stars
Water consumption per cycle	11.7L
Water rating (WELS)	4.5 stars

Controls

Control type	Soft touch LED
--------------	-----------------------

Features

Adjustable height, foldable	•
Child lock	•
Delay start	1-24hrs
Height adjustable top basket	•
Memory	•
Natural dry system	•

Performance

Noise emissions	51 dBA
Spray levels	2

Product dimensions

Depth	598 mm
Height	850 mm
Width	598 mm

Wash Programs

Auto	•
Eco	•
Glass	•
Heavy	•
Light	•
Number of wash programs	6
Rinse	•

SKU	61597
-----	-------

TEST The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may

change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. ? 2020 Haier Inc. All rights reserved.

Other product downloads available at haier.com



User Guide

A PEACE OF MIND SALE

24 Hours 7 Days a Week Customer Support

T 1300 729 948 **W**www.haier.com